

# CASE ASSEMBLY INSTRUCTIONS

1. LAY OUT THE PANELS AS SHOWN IN DRAWING BELOW
2. REMOVE FILM FROM PANELS BEFORE YOU CLICK THEM TOGETHER JUST REMEMBERING THE POSITIONS  
ONCE PANELS ARE CLICKED TOGETHER THEY ARE HARD TO SEPARATE SO MAKE SURE THEY ARE IN RIGHT PLACE. ALL THE TABS SHOULD BE AT THE TOP ONCE FITTED. THIS IS TO LOCATE THE LID AND IF YOU HAVE ADDITIONAL BOXES IT ALLOWS THEM TO STACK INTO THE BASE OF THE NEXT UNIT.

